Collomix Mixer-Clean

Short Description of Handling



After mixing, clean the mixing paddle from material freshly stuck to it with the help of Mixer-Clean. Fill Mixer-Clean with water until the brushes are covered.



Place the dirty mixing paddle between the brushes, make the mixer rotate slowly until it is completely immersed.

In order to guarantee that the mixer is cleaned properly, hold it in a slightly inclined position while it is rotating.



After a few seconds, you can pull out the cleaned mixer.

Emptying the Bucket



To open the bucket, you can use the shaft of the mixing paddle or another suitable tool. Stick the tool into the opening provided and push up the cover with the brushes.



The two retaining projections slide out of the mountings, the cover with the brushes can be taken out.



After the cover with the brushes has been taken out, the water and dirt at the bottom can be poured out.

